

ASSEMBLY MANUAL



REARSETS CBR 600 RR 2003-06

www.avdb-moto.com

avdb

REARSETS CBR 600 RR 2003-06



BRAKE PEDAL SIDE

1. *Disconnect the rear brake master cylinder from the original footrest bracket (Pay attention to the small pin on Photo n°3)*



2. *Remove the screws of the heat shield / heat protector and the screws holding the original bracket to your motorcycle's frame. We recommend you to put a new heat protector once the original bracket has been removed.*



3. *Installation of the adjustable rearsets' bracket on the frame (using the original screws) and of the footrest bracket using the screws supplied with the kit (Caution: the washers must be installed with the rounded edge towards the bearing).*



4. *Re install the master cylinder using the screws provided with our rearsets. The pedal height is adjusted via the nut/counter nut on the ball joint of the master cylinder.*



GEAR SHIFT SIDE

1. Remove the complete original footrest brackets, and then the original gear shift pedal screw. Then unscrew the ball joint from the original gear shift rod and fit the one supplied with our kit instead (use the model with "normal" right-hand thread).



2. Fix the "pivot" part in place of the original gear shift lever (Small edge on the bearing side)



3. On the gear shift rod supplied with our rearsets, install the 2 remaining ball joints and fix this rod on the gear shift and on the "pivot" part (small ball joint on the gear shift side). Then fit the original rod on the "pivot" part



Normal gear setting (1st gear down) :



Inverted gear setting (1st gear up) :



CAUTION

1/ It is very important to adjust your gear shift lever's height using the 2 gear shift rods, according to your morphology and the position of the gears (normal or reverse).

2/ All screws connections must be secured with a liquid locking agent such as "Loctite".